



Example 1


Mechanical system



Elements



Circuit



Transfer function


$$\frac{V_M(s)}{V_{\text{in}}(s)} = \frac{\frac{1}{C \cdot s + \frac{1}{R_{\text{eq}}}} \cdot \left(C \cdot s + \frac{1}{R_{\text{eq}}} \right)}{L \cdot s + \frac{1}{C \cdot s + \frac{1}{R_{\text{eq}}}} \cdot \left(C \cdot s + \frac{1}{R_{\text{eq}}} \right)} = \frac{1}{L \cdot C \cdot s^2 + \frac{L}{R_{\text{eq}}} \cdot s + 1} \cdot \frac{\left(\frac{1}{L \cdot C} \right)}{\left(\frac{1}{L \cdot C} \right)} = \frac{\frac{1}{L \cdot C}}{s^2 + \frac{1}{C \cdot R_{\text{eq}}} \cdot s + \frac{1}{L \cdot C}}$$

$$\frac{V_M(s)}{\text{Vel}_{\text{in}}(s)} = \frac{\frac{k}{M}}{s^2 + \frac{B_{\text{eq}}}{M} \cdot s + \frac{k}{M}} = \frac{\frac{20 \cdot N}{2 \cdot \text{kg} \cdot m}}{s^2 + \frac{1.6 \cdot N \cdot \text{sec}}{2 \cdot \text{kg} \cdot m} \cdot s + \left(\frac{20 \cdot N}{2 \cdot \text{kg} \cdot m} \right)} = \frac{\frac{10}{s^2 + 0.8 \cdot s + 10}}{\text{without units}}$$


same,
either way

ECE 3510 Mechanical to Electrical Examples p.2


Example 2




Example 3



Circuit with a transformer.




Circuit without a transformer.




ECE 3510 Mechanical to Electrical Examples p.3


Example 4




Circuit with a transformer.



Circuit without a transformer.




Example 5, fluids




ECE 3510 Mechanical to Electrical Examples p.3

ECE 3510 Mechanical to Electrical Examples p.4

Example 6



Circuit with a transformer.



Circuit without a transformer.

